

# EXPORTING DATA FROM PRECISION PLANTING GEN 3 20|20 DISPLAY

## Step 1

- A) Insert USB drive into the 20/20 monitor
- B) On the right side of the screen, select the Setup button



## Step 2

- A) Select Data tab on right side of screen




**Questions?** 800.260.8366 • [www.truacre.com](http://www.truacre.com) • CRS System Support 877.551.0410

Our services provide estimates or recommendations based on models. TruAcres Technology does not guarantee or warranty results. Consult your agronomist, commodities broker or other service professionals before making financial, risk management or farming decisions. Information and recommendations we provide do not modify your rights under insurance policies purchased through our affiliates. The following trademarks are used with permission: Climate FieldView® is a registered trademark of Precision Planting, LLC; GreenStar®, CommandCenter®, SeedStar®, StarFire® and SprayStar® are registered trademarks of Deere & Company Corporation; iPad® is a registered trademark of IP Application Development, LLC; and AgFiniti is a registered trademark of Ag Leader Technology, Inc.; ©2020 TruAcres Technology. All Rights Reserved.


### Step 3

- A) Select **Export** tab in the top right corner of display
- B) Then click on **Field Map Data**



### Step 4

- A) Option to select single fields or all fields. Select a single field by checking box next to the field you wish to download
- B) Once you have selected the fields you wish to download, click on **Transfer Selected Fields**
- C) If you wish to download all fields, select **Transfer All Fields**



### Step 5

- A) Once you see the screen to the right, the download is complete and you can safely remove the USB drive

### Final Step

Remember to save your data from the USB drive to your computer and make sure to compress (zip) the files prior to loading into Aeros.

